

**REMOVAL****1. SHIFTING DIFF. LOCK POSITION**

- Turn the ignition switch to ON position.
- Push the differential lock control switch to ON position and lock the rear differential.

Rotating the tires, check they are in the differential lock condition.

- Disconnect the cable from the negative terminal of the battery.

**HINT:**

At the time of installation, after installation, check that the breather plug at the end of the breather tube (inside of the LH frame) is not damaged or worn.

**2. DRAIN HYPOID GEAR OIL****3. REMOVE REAR AXLE SHAFTS (See page SA-124)****4. DISCONNECT REAR PROPELLER SHAFT**


**2WD:** See page PR-3

**4WD:** See page PR-10

**5. DISCONNECT CONNECTORS AND TUBE****HINT:**

At the time of installation, please refer to the following items.

- When connecting the tube of the harness side to the hose of the actuator side, its depth of insertion is 15 mm (0.59 in.).
- Take care that water or equivalent dose not adhere to the connector and hose.

**6. REMOVE DIFFERENTIAL CARRIER ASSEMBLY**

- Remove the 10 nuts, washers and differential carrier assembly.

**NOTICE:**

**Be careful not to damage the installation surface.**


**Torque: 25 N·m (250 kgf·cm, 18 ft·lbf)**

- Remove the gasket.

**HINT:**


At the time of installation, please refer to the following items.

- Connect the connector of the actuator to the connector of the vehicle side to check differential lock operation.
- Before installation, check the sleeves on work with switching over the differential lock control switch. After checking, lock the rear differential.



SA29V-01

## DISASSEMBLY



### 1. CHECK RUNOUT OF COMPANION FLANGE


Using a dial indicator, measure the runout of the companion flange vertical and horizontal.

**Maximum:**

**Vertical runout: 0.10 mm (0.0039 in.)**

**Horizontal runout: 0.10 mm (0.0039 in.)**

If the runout is not within the specification, replace the companion flange.




### 2. CHECK RING GEAR RUNOUT

Using a dial indicator, measure the ring gear runout.

**Maximum runout: 0.10 mm (0.0039 in.)**

If the runout is not within the specification, replace the ring gear.




### 3. CHECK RING GEAR BACKLASH

Using a dial indicator, measure the ring gear backlash.

**Backlash: 0.13 – 0.18 mm (0.0051 – 0.0071 in.)**

If the backlash is not within the specification, adjust the side bearing preload or repair if necessary.



### 4. MEASURE DRIVE PINION PRELOAD

Using a torque wrench, measure the preload of backlash between the drive pinion and ring gear.

**Preload (at starting):**

**0.5 – 0.8 N·m (5 – 8 kgf·cm, 4.3 – 6.9 in.-lbf)**

### 5. CHECK TOTAL PRELOAD

Using a torque wrench, measure the preload with the teeth of the drive pinion and ring gear in contact.


**Total preload (at starting):**

**Drive pinion preload plus**

**0.4 – 0.6 N·m (4 – 6 kgf·cm, 3.5 – 5.2 in.-lbf)**

If necessary, disassemble and inspect the differential.


### 6. CHECK TOOTH CONTACT BETWEEN RING GEAR AND DRIVE PINION (See page SA-177)

**7. REMOVE ACTUATOR**


- (a) Remove the bolt and actuator from the differential carrier.
- (b) Remove the O-ring.

**8. REMOVE INDICATOR SWITCH**


Remove the indicator switch and gasket.

**9. REMOVE SHIFT FORK SHAFT**

- (a) Using a hexagon wrench, remove the 2 straight screw plugs.
- (b) Remove the spring seat, spring and steel ball.



- (c) Using a pin punch and hammer, remove the slotted spring pin.




- (d) Remove the 2 bolts from the shaft retainer.
- (e) Using a plastic hammer, remove the shaft retainer.
- (f) Remove the shift fork shaft.




### 10. REMOVE COMPANION FLANGE

- (a) Using a chisel and hammer, unstake the nut.
- (b) Using SST to hold the flange, remove the nut.  
SST 09330-00021




- (c) Using SST, remove the companion flange.  
SST 09950-30010 (09951-03010, 09953-03010, 09954-03010, 09955-03030, 09956-03020)




### 11. REMOVE OIL SEAL AND OIL SLINGER

- (a) Using SST, remove the oil seal from the differential carrier.  
SST 09350-32014 (09308-10010)
- (b) Remove the oil slinger.




### 12. REMOVE FRONT BEARING

- Using SST, remove the front bearing from the drive pinion.  
SST 09556-22010



### 13. REMOVE DIFFERENTIAL CASE


- (a) Place matchmarks on the bearing cap and differential carrier.
- (b) Remove the 2 adjusting nut locks.
- (c) Remove the 4 bolts and 2 bearing caps.



- (d) Remove the differential case with side bearing outer race adjusting nuts and sleeve from the differential carrier.
- (e) Remove the shift fork.

#### 14. REMOVE DRIVE PINION AND BEARING SPACER

- (a) Remove the drive pinion with the rear bearing.
- (b) Remove the bearing spacer.



#### 15. REMOVE DRIVE PINION REAR BEARING


- (a) Using SST and a press, remove the bearing from the drive pinion.

SST 09950-00020

#### HINT:


If the drive pinion or ring gear are damaged, replace them as a set.

- (b) Remove the plate washer from the drive pinion.




#### 16. REMOVE FRONT AND REAR BEARING OUTER RACES AND OIL STORAGE RING

- (a) Using SST, remove the front bearing outer race.  
SST 09308-00010
- (b) Using a brass bar and hammer, remove the oil storage ring.
- (c) Using a brass bar and hammer, remove the bearing.




#### 17. REMOVE RING GEAR

- (a) Place matchmarks on the ring gear and differential case.
- (b) Using a screwdriver and hammer, unstake the lock plate.
- (c) Remove the 10 ring gear set bolts and 5 lock plates.
- (d) Using a plastic hammer, tap on the ring gear to separate it from the differential case.



#### 18. CHECK DIFFERENTIAL CASE RUNOUT

- (a) Install the differential case in the differential carrier and tighten the adjusting nut just to where there is no play in the bearing.
- (b) Using a dial indicator, measure the differential case runout.  
**Maximum case runout: 0.07 mm (0.0028 in.)**
- (c) Remove the differential case.



R15934


### 19. REMOVE SIDE BEARING FROM DIFFERENTIAL CASE

Using SST, remove the side bearing from the differential case.

SST 09950-40010 (09951-04010, 09952-04010, 09953-04020, 09954-04010, 09955-04060, 09957-04010, 09958-04010), 09950-60010 (09951-00480), 09950-60020 (09951-00730)

**HINT:**


Fix the claws of SST to the notches in the differential case.



FA2048

### 20. DISASSEMBLE DIFFERENTIAL CASE

- Place matchmarks on the LH and RH cases.
- Remove the 8 bolts uniformly, a little at a time.
- Using a plastic hammer, separate the LH and RH cases.
- Remove these parts from the differential case:
  - 2 side gears
  - 2 side gear thrust washers
  - Spider
  - 4 pinion gears
  - 4 pinion gear thrust washers



RD8149

### 21. INSPECT SLEEVE

- Install the sleeve to the differential case (LH) and check it moves smoothly.
- Install the sleeve to the side gear and check it moves smoothly.



SA1987


### 22. MEASURE CLEARANCE OF SHIFT FORK AND SLEEVE

Using a feeler gauge, measure the clearance between the shift fork and sleeve.

**Clearance (Reference):**

0.15 – 0.35 mm (0.006 – 0.014 in.)







## REPLACEMENT

### REPLACE COMPANION FLANGE DUST DEFLECTOR

(a) Using SST and a press, remove the dust deflector.  
SST 09950-00020





(b) Using SST and a press, install a new dust deflector.  
SST 09726-40010



## REASSEMBLY

### 1. ASSEMBLE DIFFERENTIAL CASE

- (a) Apply all of the sliding and rotating surfaces with gear oil.
- (b) Install the side gear thrust washer to the side gear.
- (c) Install the side gear to the RH case.



- (d) Install the 4 pinion gears and pinion gear thrust washers to the spider.
- (e) Install the pinion gear with spider to the RH case.
- (f) Using a dial indicator, measure the side gear backlash with holding the side gear and spider.

**Backlash: 0.05 – 0.20 mm (0.0020 – 0.0079 in.)**


#### HINT:

- Measure at all 4 locations.
- Measure the backlash at the RH case and the LH case.


If the backlash is not within the specification, install a thrust washer of a different thickness.

#### Thrust washer thickness

Thickness	mm (in.)	Thickness	mm (in.)
	0.9 (0.035)		1.2 (0.047)
	1.0 (0.039)		1.3 (0.051)
	1.1 (0.043)		-



- (g) Install the side gear and side gear thrust washer to the RH case.
  - (h) Install the pinion gears and spider to the RH case.
  - (i) Install the side gear and side gear thrust washer to the RH case.
  - (j) Align the matchmarks on the LH and RH cases.
  - (k) Torque the 8 bolts uniformly, a little at a time.
- Torque: 47 N·m (480 kgf·cm, 35 ft·lbf)**



### 2. INSTALL SIDE BEARINGS

Using SST and a press, install the side bearings on the differential case.

SST 09950-60010 (09951-00480, 09951-00550),  
09950-60020 (09951-00730)

